Table of contents

1 Introduction
2 Safety instructions
3 Intended use
4 Scope of delivery
5 Overview of the device
6 Technical data
7 Before first use
8 Operation
9 Cleaning and maintenance
10 Troubleshooting
11 Disposal
12 Warranty

Introduction

Thank you for choosing the PSD THE IDEAL WORKPLACE. This manual will help you to get the most out of your new device. Please read it carefully before first use and keep it for future reference.

Safety instructions

Please observe the following safety instructions to avoid injuries and damage to the device.

- Do not exceed the maximum load capacity.
- Keep children and pets away from the moving parts.
- Do not use the device outdoors or in damp rooms.
- Unplug the device before cleaning or maintenance.
- Never operate the device with a damaged cable.
- Do not modify the device in any way.

Intended use

The PSD THE IDEAL WORKPLACE is designed for the ergonomic adjustment of desks in private and commercial environments. It is not suitable for industrial use or for lifting persons.

Scope of delivery

Please check the contents of the box for completeness after unpacking.

- 1 × Control unit
- 2 × Drive columns
- 1 × Mains cable
- 1 × Hand switch
- 1 × Mounting kit
- 1 × Operating manual

Overview of the device

Technical data

Model	PSD-1
Lifting range	620 – 1270 mm
Maximum load	120 kg
Lifting speed	38 mm/s
Mains voltage	230 V / 50 Hz
Power consumption	350 W
Noise level	< 55 dB(A)
Weight	38 kg

Before first use

Remove all packaging material and dispose of it properly. Check the device for visible damage. Do not connect the device to the mains if it is damaged.

Operation

Press the up or down button on the hand switch to adjust the height. Release the button when the desired height is reached. The device stops automatically at the upper and lower limit.

Cleaning and maintenance

Clean the surfaces with a soft, slightly damp cloth. Do not use abrasive cleaners or solvents. Check the screw connections every six months and tighten them if necessary.

Troubleshooting

If the device does not work, first check the mains connection and the fuse. If the problem persists, contact customer service. Do not attempt to repair the device yourself.

Disposal

Dispose of the device and packaging in accordance with local regulations. Old electrical devices must not be disposed of with household waste.

Warranty

We grant a warranty of 24 months from the date of purchase. The warranty does not cover damage caused by improper use or failure to observe the safety instructions.