



Grommet Top Curtain Install

- Remove curtain rod from brackets. Remove finials from rod.
- Slide your curtain panels onto the rod, and finish by securing the two finials.
- Lift up your completed curtain rod and carefully set it on the brackets. Secure the rod to your brackets by tightening the adjustment screws. Repeat on the other side.
- Finally, fan out the material on the rod to the inside edges of your brackets.
- And that's it. You have successfully hung your grommet top curtains.