




### **Notes:**

1. Reinforced Inner Rubber Hose
2. Inner Rubber Hose Ends made of BRASS
3. BRASS Fittings, fits all Standard Hand Showers
4. The Fittings are 1/2" Strait Pipe Threading, NOT tapered, thus water seal is created with compression of rubber washers (included). Rubber Washers must be inserted in fittings and fittings tightly fastened. Plumbers (Teflon) tape (included) should NOT be used UNLESS leaking develops after installation (due to possible non-compatibility of other fitting with hose fitting).
5. Conical Hose End will fit perfectly all Modona Bathroom's shower arm mounts (SAM01-A) and wall mounts and most other brands; however, not every brand uses the same exact shape and size of mount. If conical end does not fit well, please consider using Modona's SAM01-A.

### **Installation :**

1. Insert washer with screen into conical end of hose
2. Attach conical end of hose to hand shower (turn clockwise)
3. Insert washer into hex end of hose
4. Attach hex end of hose to valve of water outlet pipe (turn clockwise)