
- Thank you for purchasing our kitchen faucet
- Please read this manual carefully before you install it
- Please keep this maunal properly for the reference in the future



USER MANUAL



NO.	PART NAME
1	Faucet
2	Mounting shank
3	Rubber washer
4	Metal washer
5	Mounting nut
6	Screw
7	Quick connect adapter
8	Supply lines
9	Hose weight assembly
10	Deck plate
11	Transform adapters

Model PK-018-DP

Read all instructions prior to installation.


⚠ CAUTION

Failure to read these instructions prior to installation may result in personal injury, property damage, or product failure. Manufacturer assumes no responsibility for product failure due to improper installation.

You may need:




1




Turn off hot and cold water supplies at angle stops.

2A




Slide mounting shank (2) through sink from above, then slide the shank (2) through the rubber washer (3), then through the metal washer (4).
Ensure base is aligned with sink ,fully tightening mounting nut (5), tightening the screw (6).

2B




If the sink has three holes, Slide mounting shank (2) through deck plate (10) and sink from above, then slide the shank (2) through the rubber washer (3), then through the metal washer (4).
Ensure base is aligned with sink ,fully tightening mounting nut (5), tightening the screw (6).

3A




If the thread of the angle valve is 3/8'', thread hot and cold supply lines (8) to angle valves using wrench.

3B




If the thread of the angle valve is 1/2'', first thread the transform adapters (11) (transform 1/2'' male thread to 3/8'' male thread) to angle valves using wrench, then thread hot and cold supply lines (8) to transform adapters (11).

4




Push hose end onto the end of the quick connect adapter(7).
Push in as far as possible until a “click” is heard. Tug downward on pull down hose to test engagement.

5



Install Hose weight assembly.

6



Turn on both water supplies at angle stops and faucet handle, check for leaks at all connections made during this installation, Refer back to the appropriate installation instructions and retighten if necessary.